



## Christchurch (NZ) Convention Centre

1998

Hauptwerk	I.	C – c4	Schwellwerk	II.	C – c4	Bombarde	III.	C – c4	Pedal	C – g1
Principal		16'	Pommer		16'	Cornet	V	8'	Untersatz	32'
Principal		8'	Principal		8'	Bombarde		16'	Principal	16'
Gedackt		8'	Bourdon		8'	Bombarde		8'	Subbaß	16'
Flûte harmonique		8'	Gamba		8'	Bombarde		4'	Principal	8'
Octave		4'	Voix céleste		8'				Flöte	8'
Spitzflöte		4'	Prestant		4'				Choralbaß	4'
Superoctave		2'	Flûte à cheminée		4'				Kontraposane	32'
Mixtur	VI	2'	Nazard		2 2/3'				Posaune	16'
Scharff	IV	1'	Flûte		2'				Fagott	16'
Cornet	V	8'	Terz		1 3/5'				Trompete	8'
Trompette		16'	Plein Jeu	VI-VIII	2 2/3'					
Trompette		8'	Basson		16'					
Trompette		4'	Trompette harm.		8'					
			Hautbois		8'					
			Clairon		4'					
			Tremulant							
									<b>Couplers:</b>	
									II/I, III/I, III/II	
									I/P, II/P, III/P	

**Key action:**  
mechanical

**Stop action:**  
electric

**Casework:**  
spruce, painted

**Combinations:**  
12 generals on 16 levels  
4 crescendi (adjustable)  
sequence forw.-backw.  
tutti

*Rieger*

Rieger-Orgelbau GesmbH  
A-6858 Schwarzach-Vbg., Hofsteigstraße 120  
T +43 (0) 5572/58132-0, F +43(0) 5572/58132-6  
www.rieger-orgelbau.com, rieger@rieger-orgelbau.com